

③Put the motor bracket on and screw the standard M4 screws into the hole shown, but please do not lock them now.





